

Frontside

Disposal of product and battery

This product contains electrical components and a battery. The product and the battery must not be disposed of with household waste. End users are legally obliged to collect waste batteries separately and return them. Remove the battery before disposal and return the product and battery separately to suitable collection or return points.

This product is not suitable for room lighting. The LED is intended solely to illuminate the jewellery item inside the case.

LESER GmbH
Gottlieb-Daimler-Straße 11
77933 Lahr - Germany

Contact
leser@leser.de
www.leser.de



Batteriewechsel

1. Öffnen Sie das Etui vollständig.
2. Heben Sie das Deckelkissen an der Aussparung für das LED-Licht vorsichtig mit einem geeigneten, flachen Gegenstand an. Bitte achten Sie darauf, das Material nicht zu beschädigen.
3. Entnehmen Sie die Batterie und ersetzen Sie diese durch eine neue Batterie des Typs CR2016. Achten Sie beim Einsetzen auf die richtige Polarität (+/-).
4. Setzen Sie das Deckelkissen anschließend wieder sauber ein.

Batterietyp: CR2016, 3 V

Batteriehinweis: Nur Batterien des angegebenen Typs verwenden. Batterien außerhalb der Reichweite von Kindern aufbewahren.

Artikel: 5530XX.XXXXXXXX LED Serie

Backside

Entsorgung von Produkt und Batterie

Dieses Produkt enthält elektrische Bauteile und eine Batterie. Produkt und Batterie dürfen nicht über den Hausmüll entsorgt werden. Endnutzer sind gesetzlich verpflichtet, Altbatterien getrennt zu sammeln und zurückzugeben. Entnehmen Sie die Batterie vor der Entsorgung und geben Sie Produkt und Batterie getrennt bei geeigneten Sammel- oder Rückgabestellen ab.

Dieses Produkt ist nicht zur Raumbelichtung geeignet. Die LED dient ausschließlich der Beleuchtung des Schmuckstücks im Etui.

LESER GmbH
Gottlieb-Daimler-Straße 11
77933 Lahr

Kontakt
leser@leser.de
www.leser.de



Battery replacement

1. Open the case completely.
2. Carefully lift the lid cushion at the cut-out for the LED light using a suitable flat object. Please take care not to damage the material.
3. Remove the battery and replace it with a new battery of type CR2016. Make sure to insert the battery with the correct polarity (+/-).
4. Then place the lid cushion back properly.

Battery type: CR2016, 3 V

Battery note: Only use batteries of the specified type. Keep batteries out of the reach of children.

Item: 5530XX.XXXXXXXX LED Serie